



GB Instruction manual COTTON FIX:

COTTON FIX has a self-adhesive coating on one side that is protected by a peel-off paper film. **Machine embroidery:** cut off the desired length of COTTON FIX from the roll and stretch it into the embroidery frame with the protective film facing upwards. Carefully score the protective film in the centre with a diagonal cross using the points of the scissors (fig 1) Caution! – only score the protective film and not the backing. Remove the protective film to provide a surface that is somewhat larger than the embroidery motif (fig. 2) Place the fabric onto the open adhesive surface and finger press on firmly (fig. 3). After completing the embroidery carefully peel the fabric from the backing (fig. 4) – the embroidery will peel off the film on its own accord.

Quilting: Quilting patterns that only consist of outlines (e.g. hearts or circles) can be transferred onto a quilt with ease by means of COTTON FIX. The quilt motif should be drawn onto the backing in pencil. Cut out the motif along the outline, peel off the protective film and stick the motif onto the fabric. Quilt along the outside edge of the motif. Remove COTTON FIX after quilting.

Hand appliqué: transfer the appliqué motif precisely onto the backing side of COTTON FIX and cut out accurately. Peel off the protective film and stick the motif onto the right side of the fabric. Cut out the motif with a seam allowance of approximately 5 mm and sew onto the fabric taking care to avoid dropped stitches, so that the seam allowance gradually folds under the appliqué. After completing the appliqué, peel the COTTON FIX off the fabric. **Note:** always keep COTTON FIX enclosed in the clam shell pack. This will protect your embroidery backing from dirt, damp and dehydration.